

# Bourdon tube pressure gauge Stainless steel version Models 232.50, 233.50

WIKA data sheet PM 02.02



for further approvals  
see page 2

## Applications

- With liquid-filled case for applications with high dynamic pressure loads or vibrations <sup>1)</sup>
- For gaseous and liquid aggressive media that are not highly viscous or crystallising, also in aggressive ambience
- Process industry: Chemical/petro-chemical, power stations, mining, on- and offshore, environmental technology, machine building and general plant construction

## Special features

- Excellent load-cycle stability and shock resistance
- All stainless steel construction
- German Lloyd, Gosstandart and DVGW approval
- Scale ranges up to 0 ... 1,600 bar

## Description

### Design

EN 837-1

### Nominal size in mm

63, 100, 160

### Accuracy class

NS 63: 1.6

NS 100, 160: 1.0

### Scale ranges

NS 63: 0 ... 1 to 0 ... 1,000 bar

NS 100: 0 ... 0.6 to 0 ... 1,000 bar

NS 160: 0 ... 0.6 to 0 ... 1,600 bar

or all other equivalent vacuum or combined pressure and vacuum ranges

<sup>1)</sup> Model 233.50



Bourdon tube pressure gauge model 232.50

### Pressure limitation

NS 63:	Steady:	3/4 x full scale value
	Fluctuating:	2/3 x full scale value
	Short time:	Full scale value
NS 100, 160:	Steady:	Full scale value
	Fluctuating:	0.9 x full scale value
	Short time:	1.3 x full scale value

### Permissible temperature

Ambient:	-40 ... +60 °C without liquid filling
	-20 ... +60 °C gauges with glycerine filling <sup>1)</sup>
Medium:	+200 °C maximum without liquid filling
	+100 °C maximum with liquid filling <sup>1)</sup>

### Temperature effect

When the temperature of the measuring system deviates from the reference temperature (+20 °C):  
max. ±0.4 %/10 K of full scale value

### Ingress protection

IP 65 per EN 60529 / IEC 60529

## Standard version

### Process connection

Stainless steel 316L (NS 63: 1.4571),  
Lower mount (LM) or lower back mount (LBM), NS 63 centre  
back mount (CBM)

NS 63: G ¼ B (male), 14 mm flats  
NS 100, 160: G ½ B, 22 mm flats

### Pressure element

Stainless steel 316L  
C-type or helical type

### Movement

Stainless steel

### Dial

Aluminium, white, black lettering,  
NS 63 with pointer stop pin

### Pointer

Aluminium, black

### Case

Stainless steel, with pressure relief at case circumference,  
12 o'clock (NS 63) and on the back of the case (NS 100  
and 160),  
Scale ranges  $\leq 0 \dots 16$  bar with compensating valve to vent  
case

### Window

Laminated safety glass  
(NS 63: Polycarbonate)

### Ring

Cam ring (bayonet type), stainless steel

### Filling liquid (for model 233.50)

Glycerine 99.7 %  
(Glyzerine 86.5 % for scale range  $\leq 0 \dots 2.5$  bar)

## Options

- Other process connection
- Sealings (model 910.17, see data sheet AC 09.08)
- Assembly on diaphragm seals see product review DS
- Measuring system Monel (model 26x.50, not with NS 160  
back mount connection)
- Measuring system stainless steel 1.4571
- Surface or panel mounting flange, stainless steel
- Panel mounting flange, polished stainless steel
- Triangular bezel, polished stainless steel, with clamp
- Ambient temperatures  $-40$  °C: Silicone oil filling
- Limit indicator at NS 100 and 160, see data sheet  
SP 09.03
- Pressure gauge with switch contacts, see model  
PGS23.1x0, data sheet PV 22.02
- Pressure gauge with electrical output signal, see model  
PGT23.100/160, data sheet PV 12.04

## Special versions

**Gauges for ammonia plants** (NS 100 and 160)  
With temperature scale for refrigerant R 717 (NH<sub>3</sub>) in °C,  
Scale ranges:  $-1 \dots 0 \dots 15$  bar or  $-1 \dots 0 \dots 26$  bar

## CE conformity

### Pressure equipment directive

97/23/EC, PS > 200 bar, module A, pressure accessory

### ATEX directive <sup>1)</sup>

Ignition protection type „c“, constructive safety

## Approvals

- **GL**, ships, shipbuilding (e.g. offshore), Germany
- **DVGW**, safety (e.g. electrical safety, overpressure, ...),  
Germany
- **EAC**, import certificate, customs union Russia/Belarus/  
Kazakhstan
- **GOST**, metrology/measurement technology, Russia
- **KBA**, automotive, European Community
- **CRN**, safety (e.g. electr. safety, overpressure, ...), Canada
- **KOSHA**, ignition protection type „i“ - intrinsic safety,  
South Korea

## Certificates <sup>1)</sup>




- 2.2 test report per EN 10204 (e.g. state-of-the-art  
manufacturing, material proof, indication accuracy)
- 3.1 inspection certificate per EN 10204 (e.g. indication  
accuracy)

<sup>1)</sup> Option

Approvals and certificates, see website

# Dimensions in mm

## Standard version



NS	Dimensions in mm									Weight in kg			
	a	b	b <sub>1</sub>	b <sub>2</sub>	D <sub>1</sub>	D <sub>2</sub>	e	f	G	h ±1	SW	Model 232.50	Model 233.50
63	9.5	33	33	57	63	62	11.5	-	G ¼ B	54	14	0.16	0.20
100	15.5	49.5	49.5	83	101	99	17.5	30	G ½ B	87	22	0.60	0.90
160	15.5	49.5 <sup>2)</sup>	49.5 <sup>2)</sup>	83 <sup>1)</sup>	161	159	17.5	50	G ½ B	118	22	1.10	2.00

Process connection per EN 837-1 / 7.3

- 1) Plus 16 mm with scale ranges ≥ 100 bar
- 2) Plus 16 mm with scale range 1,600 bar

## Ordering information

Model / Nominal size / Scale range / Connection size / Connection location / Options

© 2000 WIKA Alexander Wiegand SE & Co. KG, all rights reserved.  
The specifications given in this document represent the state of engineering at the time of publishing.  
We reserve the right to make modifications to the specifications and materials.



**WIKA Alexander Wiegand SE & Co. KG**  
Alexander-Wiegand-Straße 30  
63911 Klingenberg/Germany  
Tel. +49 9372 132-0  
Fax +49 9372 132-406  
info@wika.de  
www.wika.de