

# OEM pressure transmitter with thin-film technology

## For mobile hydraulics

### Model MH-2

WIKA data sheet PE 81.37

#### Applications

- Load monitoring
- Load moment limitation
- Hydraulic drive control

#### Special features

- For extreme operating conditions
- Compact and robust design



Pressure transmitter model MH-2

#### Description

Shock and vibration resistance, resistance to pressure spikes (CDS system) and an ingress protection of up to IP 69K make the model MH-2 pressure transmitter especially qualified for the harsh operating conditions in mobile hydraulics. Even extreme temperature shocks do not affect its performance.

The case is made of a highly resistant glass-fibre reinforced plastic (PBT). This material is successfully used within the automotive industry.

A metallic shield inside the instrument provides excellent EMC characteristics in accordance with EN 61326, thus ensuring reliable operation, even under high exposures of up to 100 V/m.

The hermetically-welded thin-film measuring cell ensures long-term leak-tightness, without the need for additional sealing materials. Especially in applications with high dynamic load cycles, the thin-film measuring cell features high long-term stability and load-cycling resistance.

## Measuring ranges

Gauge pressure in bar							
Measuring range	0 ... 40	0 ... 60	0 ... 100	0 ... 160	0 ... 250	0 ... 400	0 ... 600
Overpressure limit	80	120	200	320	500	800	1,200
Burst pressure	400	550	800	1,000	1,200	1,700	2,400

Measuring ranges < 40 bar on request

### Vacuum tightness

Yes

## Output signals

Selectable versions	
Signal type	Signal
Current (2-wire)	4 ... 20 mA
Voltage (3-wire)	DC 0 ... 10 V
	DC 1 ... 5 V
Ratiometric	DC 0.5 ... 4.5 V

Other output signals available on request

### Load in $\Omega$

- 4 ... 20 mA:  $\leq (\text{power supply} - 10 \text{ V}) / 0.02 \text{ A}$
- DC 0 ... 10 V:  $> 5 \text{ k}$
- DC 1 ... 5 V:  $> 2.5 \text{ k}$
- DC 0.5 ... 4.5 V:  $> 4.5 \text{ k}$

## Voltage supply

### Power supply

The power supply depends on the selected output signal

- 4 ... 20 mA: DC 10 ... 36 V
- DC 0 ... 10 V: DC 14 ... 36 V
- DC 1 ... 5 V: DC 8 ... 36 V
- DC 0.5 ... 4.5 V: DC 4.5 ... 5.5 V

## Reference conditions (per IEC 61298-1)

### Temperature

15 ... 25 °C

### Atmospheric pressure

860 ... 1,060 mbar

### Humidity

45 ... 75 % relative

### Power supply

DC 24 V

### Mounting position

Calibrated in vertical mounting position with pressure connection facing downwards.

## Accuracy data

### Accuracy at reference conditions

Maximum:  $\leq \pm 1$  % of span

Including non-linearity, hysteresis, zero offset and end value deviation (corresponds to measured error per IEC 61298-2).

### Non-linearity (per IEC 61298-2)

Maximum:  $\leq \pm 0.4$  % of span BFSL

Typical:  $\leq \pm 0.25$  % of span BFSL

### Temperature error in rated temperature range

Rated temperature range:  $-40 \dots +100$  °C

Maximum:  $\pm 0.15$  % of span/10K

Typical:  $\pm 0.08$  % of span/10K

### Settling time

$\leq 2$  ms

### Long-term stability

Typical:  $\leq \pm 0.2$  % of span/year

## Operating conditions

### Ingress protection (per IEC 60529)

The ingress protection depends on the type of electrical connection.

- Circular connector M12 x 1 (4-pin): IP 67
- Metri-Pack series 150 (3-pin): IP 67
- Bayonet connector DIN 72585 (4-pin): IP 69K
- AMP Superseal 1.5 (3-pin): IP 67
- AMP Micro Quadlock (3-pin): IP 67
- Deutsch DT04-3P (3-pin): IP 67
- Cable outlet: IP 69K

The stated ingress protection only applies when plugged in using mating connectors that have the appropriate ingress protection.

### Vibration resistance

20 g (per IEC 60068-2-6, under resonance)

### Shock resistance

500 g (per IEC 60068-2-27, mechanical)

### Temperatures

Permissible temperature ranges for:

- Ambient:  $-40 \dots +100$  °C
- Medium:  $-40 \dots +125$  °C
- Storage:  $-40 \dots +100$  °C

## Process connections

### Selectable versions

Process connection per	Thread size
DIN 3852-E	G ¼ A M14 x 1.5
ANSI/ASME B1.20.1	¼ NPT
SAE J514 Fig.34B	7/16-20 UNF-2A

### Sealings

#### Selectable versions

Thread size	Standard	Option
G ¼ A	NBR	FKM
7/16-20 UNF-2A	O-ring BOSS from FKM	-

The sealings listed under "Standard" are included in the delivery.

### CDS system

All process connections are available with the CDS system. The diameter of the pressure channel is reduced in order to counteract pressure spikes and cavitation (see fig.1).




Fig. 1: Reduced diameter of the pressure channel

## CE conformity

### EMC directive

2004/108/EC, EN 61326 emission (group 1, class B) and immunity (industrial application)

### Pressure equipment directive

97/23/EC

## Materials

### Wetted parts

Stainless steel

### Non-wetted parts

Highly resistant glass-fibre reinforced plastic (PBT)

## Electrical connections

### Short-circuit resistance

S<sub>+</sub> vs. U<sub>-</sub>

### Reverse polarity protection


U<sub>B</sub> vs. U<sub>-</sub>


(no reverse polarity protection with ratiometric output signal)


### Insulation voltage


DC 500 V


### Connection diagrams


Circular connector M12 x 1 (4-pin)			
		2-wire	3-wire
	U <sub>B</sub>	1	1
	U <sub>-</sub>	3	3
	S <sub>+</sub>	-	4


Metri-Pack series 150 (3-pin)			
		2-wire	3-wire
	U <sub>B</sub>	B	B
	U <sub>-</sub>	A	A
	S <sub>+</sub>	-	C

Bayonet connector DIN 72585 (4-pin)			
		2-wire	3-wire
	U <sub>B</sub>	1	1
	U <sub>-</sub>	2	2
	S <sub>+</sub>	-	3

AMP Superseal 1.5 (3-pin)			
		2-wire	3-wire
	U <sub>B</sub>	3	3
	U <sub>-</sub>	1	1
	S <sub>+</sub>	-	2

AMP Micro Quadlock (3-pin)			
		2-wire	3-wire
	U <sub>B</sub>	3	3
	U <sub>-</sub>	1	1
	S <sub>+</sub>	-	2

Deutsch DT04-3P (3-pin)			
		2-wire	3-wire
	U <sub>B</sub>	A	A
	U <sub>-</sub>	B	B
	S <sub>+</sub>	-	C

Cable outlet			
		2-wire	3-wire
	U <sub>B</sub>	brown	brown
	U <sub>-</sub>	green	green
	S <sub>+</sub>	-	white

U <sub>B</sub>	Positive power supply terminal
U <sub>-</sub>	Reference potential
S <sub>+</sub>	Positive output terminal

Wire cross-section 0.75 mm<sup>2</sup> (with end splices)


Cable diameter 6.6 mm

Cable length 0.5 m or 2 m


## Dimensions in mm

### Pressure transmitter model MH-2


with circular connector M12 x 1




with Metri-Pack series 150




with bayonet connector DIN 72585




with Deutsch DT04-3P




with AMP Micro Quadlock




with AMP Superseal 1.5




with cable outlet




## Process connections



G	L1
G ¼ A DIN 3852-E	14
M14 x 1.5 DIN 3852-E	14



G	L1
7/16-20 UNF	12



G	L1
¼ NPT	13

For information on tapped holes and welding sockets, see Technical information IN 00.14 at [www.wika.com](http://www.wika.com).

## Ordering information

Model / Measuring range / Output signal / Process connection / Sealing / Electrical connection

© 2011 WIKA Alexander Wiegand SE & Co. KG, all rights reserved.  
The specifications given in this document represent the state of engineering at the time of publishing.  
We reserve the right to make modifications to the specifications and materials.



**WIKAL Alexander Wiegand SE & Co. KG**  
Alexander-Wiegand-Straße 30  
63911 Klingenberg/Germany  
Tel. +49 9372 132-0  
Fax +49 9372 132-406  
info@wika.de  
www.wika.de