Capsule pressure gauge, copper alloy or stainless steel Standard version, NS 50 and 63 Models 611.10 and 631.10

WIKA data sheet PM 06.01











for further approvals see page 3

Applications

- Pressure gauge for use in a protected environment
- Medical, vacuum, environmental, laboratory technology, for contents measurement and filter monitoring
- For gaseous, dry and non-aggressive media
- Model 631.10 also for aggressive media

Special features

- Zero point setting in front
- Special connection location on request
- Low scale ranges from 0 ... 25 mbar



Capsule pressure gauge, model 611.10

Description

The model 611.10 and 631.10 capsule pressure gauges are based upon the proven capsule measuring system. The capsule measuring principle is particularly suitable for low pressures. On pressurisation, the expansion of the capsule element, proportional to the incident pressure, is transmitted to the movement and indicated.

The case is made from black lacquered steel with a snapfitted window. The material of the process connection is a copper alloy with model 611.10 and stainless steel with model 631.10. The modular design enables a multitude of combinations of case materials, process connections, nominal sizes and scale ranges. Due to this high variance, the instrument is suitable for use in a wide range of applications within industry.

For mounting in control panels, the capsule pressure gauges can, depending on the process connection, be fitted with a surface mounting flange or with a triangular bezel and mounting bracket.

WIKA data sheet PM 06.01 · 09/2017





Standard version

Design

EN 837-3

Nominal size in mm

50,63

Accuracy class

1.6

Scale ranges

NS 50: 0 ... 60 mbar to 0 ... 600 mbar NS 63: 0 ... 25 mbar to 0 ... 600 mbar or all other equivalent vacuum or combined pressure and vacuum ranges

Pressure limitation

Steady: Full scale value

Fluctuating: 0.9 x full scale value

Permissible temperature

Ambient: -20 ... +60 °C Medium: ≤ 100 °C

Temperature effect

When the temperature of the measuring system deviates from the reference temperature (+20 $^{\circ}$ C): max. ±0.6 %/10 K of full scale value

Ingress protection per IEC/EN 60529

IP32

Process connection

Model 611.10: Copper alloy Model 631.10: Stainless steel Lower mount or back mount (NS 50: Only back mount) G ¼ B (male), SW 14

Pressure element

Model 611.10: Copper alloy Model 631.10: Stainless steel

Sealing

NBR

Movement

Copper alloy

Zero point setting

In front

Dial

Aluminium, white, black lettering

Pointer

Aluminium, black

Case

Steel, black

Window

Clear non-splintering plastic, domed, snap-fitted in case

Options

- Other process connection 1)
- Sealings ¹⁾ (model 910.17, see data sheet AC 09.08)
- Stainless steel case 1)
- Overload ¹⁾ or vacuum safety ¹⁾ with scale ranges < 40 mbar: 3 x full scale value scale ranges ≥ 40 mbar: 10 x full scale value
- Slip-on bezel
- Panel or surface mounting flange
- Triangular bezel with clamp

1) only for NS 63

Approvals

Logo	Description	Country
CE	EU declaration of conformity ■ Pressure equipment directive PS > 200 bar; module A, pressure accessory	European Union
ERE	EAC (option) ■ Pressure equipment directive ■ Hazardous areas	Eurasian Economic Community
©	GOST (option) Metrology, measurement technology	Russia
6	KazInMetr (option) Metrology, measurement technology	Kazakhstan
-	MTSCHS (option) Permission for commissioning	Kazakhstan
(BelGIM (option) Metrology, measurement technology	Belarus
•	UkrSEPRO (option) Metrology, measurement technology	Ukraine
	Uzstandard (option) Metrology, measurement technology	Uzbekistan
-	CPA (option) Metrology, measurement technology	China


Certificates (option)


- 2.2 test report
- 3.1 inspection certificate

Approvals and certificates, see website

Dimensions in mm

Standard version





NS	S Dimensions in mm								Weight in kg
	а	b	b ₁	b ₂	D	G	h ±1	SW	
50	-	-	28	47	50	G 1/4 B	-	14	0.09
63	9.5	40	36.5	54.5	63	G 1/4 B	51	14	0.20

Process connection per EN 837-3 / 7.3

Ordering information

Model / Nominal size / Scale range / Connection size / Connection location / Options

© 11/2008 WIKA Alexander Wiegand SE & Co. KG, all rights reserved.

The specifications given in this document represent the state of engineering at the time of publishing. We reserve the right to make modifications to the specifications and materials.

WIKA data sheet PM 06.01 · 09/2017

Page 4 of 4



WIKA Alexander Wiegand SE & Co. KG Alexander-Wiegand-Straße 30 63911 Klingenberg/Germany Tel. +49 9372 132-0

Fax +49 9372 132-406

info@wika.de www.wika.de